

Beghelli


INSTALLATION INSTRUCTIONS

GIRA SOLE IN-GROUND	
WATTAGE	34W
VOLTAGE	120-277V 50/60Hz
WET LOCATION	YES
OPERATION	HT (AC ONLY)
AMBIENT TEMPERATURE	-40°C (-40°F)/40°C (104°F)
WEIGHT	
DIMENSION	Ø11.9" X 8.9" H





- 1. CAUTION! ALWAYS MAKE SURE THE POWER IS TURNED OFF before starting the installation
- 2. Measure, locate fixture's position, and mark locations for the brackets.
- 3. Secure brackets to ceiling as shown below. (HARDWARE BY OTHERS)
- Wiring fixture to power supply, shall be performed by a certified electrician, and wired in a manner that complies with all local and national electrical codes, as well as the manufacturer's wiring diagram.



BEGHELLI USA

3810 Executive Way Miramar, Florida 33025, USA

Tel: (954) 442-6600 Toll Free: 1 (800) 726-4316

BEGHELLI MÉXICO

Av. del Marqués No. 70 Int.4. Parque Industrial Bernardo Quintana CP.76246 El Marqués, Qro, México Tel: 1 52 (442) 221.62.15/221.64.39